

## - Basic Voice over IP -

### Voice over IP (VoIP)

**Voice over IP (VoIP)** is a digital form of transport for voice transmissions, replacing analog phone systems.

The benefits of VoIP are considerable:

- **Better use of bandwidth** - Traditional voice requires a dedicated 64-Kbps circuit for each voice call, while VoIP calls can use considerably less. Additionally, *no* bandwidth is consumed when no call is being made.
- **Single form of cabling** – Reduces implementation and maintenance costs by having a standardized and consolidated cabling and equipment infrastructure.
- **Cost savings from integration into the data network** – Toll charges for inter-office voice communication can be avoided by routing voice traffic across existing data lines.
- **Integration into devices beyond telephones**

Basic VoIP components can include:

- **Phones** – including both analog and IP phones.
- **Gateways** – allows a non-VoIP (analog) device to communicate with the VoIP network, or a VoIP device to communicate with an analog network.
- **Application Servers** – provides required applications to VoIP phones.
- **Gatekeepers** – maps phone numbers to IP addresses, and grants permission for call setup
- **Call Agents** – handles call routing and setup.

**Digital Signal Processors (DSP's)** are used by devices to perform analog-to-digital and digital-to-analog conversions. Both VoIP phones and gateways utilize DSP technology.

\* \* \*

All original material copyright © 2007 by Aaron Balchunas ([aaron@routeralley.com](mailto:aaron@routeralley.com)), unless otherwise noted. All other material copyright © of their respective owners.

This material may be copied and used freely, but may not be altered or sold without the expressed written consent of the owner of the above copyright. Updated material may be found at <http://www.routeralley.com>.

## VoIP Packetization

Voice traffic must be **packetized** as it traverses the IP network. Sound is first captured using a microphone on the headset. A voice call requires a 4 kHz (4000 Hz) channel. To convert analog voice to a digital format, **samples** of the frequency and amplitude of the analog wave are made. Thus, **sampling** merely takes a snapshot of the signal at a given point in time.

The *amplitude height* of each snapshot is assigned a numeric value, through a process called **quantization**. This numeric value is then represented as a sequence of binary digits (usually 8) through a process called **encoding**.

The **Nyquist sampling theorem** dictates that the analog wave should be sampled at a rate of twice the channel's frequency range:

$$f_s = 2(\text{freq. range})$$

Thus, assuming a range of 4000 Hz, this requires a rate of 8000 samples per second. Remember that each sample is assigned an 8-bit value to represent the amplitude height at the time of sampling. Thus, a dedicated 64,000-bit channel (8-bits x 8000 samples per second) was traditionally required for a voice call (hence a DS0 being 64Kbps).

The process of encoding an analog signal into digital format is handled by a **codec** (coder-decoder). The codec usually provides a level of **compression**. The efficiency of the compression varies with the codec used; however, more compression generally degrades sound quality. Various codecs include:

- **G.711** – uses 64 Kbps for a voice call
- **G.726** – uses 32, 24, or 16 Kbps for a voice call
- **G.728** – uses 16 Kbps for a voice call
- **G.729** – uses 8 Kbps for a voice call

Generally, the analog sound is chopped into *groups* of **10ms**, and then sampled and encoded. Each group (or often two groups, for a total of **20ms** of analog sound) is **encapsulated** within an IP packet. At the transport layer, **Real-Time Protocol (RTP)** is used instead of TCP. RTP operates on top of UDP.

When the voice packet arrives at a digital-to-analog gateway, the headers are stripped off, and the sound is reassembled as an analog stream.

\* \* \*

All original material copyright © 2007 by Aaron Balchunas ([aaron@routeralley.com](mailto:aaron@routeralley.com)), unless otherwise noted. All other material copyright © of their respective owners.

This material may be copied and used freely, but may not be altered or sold without the expressed written consent of the owner of the above copyright. Updated material may be found at <http://www.routeralley.com>.

## **Cisco VoIP Integration**

Cisco devices operating as VoIP gateways can contain a variety of *analog* interfaces, including:

- **Foreign Exchange Station (FXS) interface** – connects to an analog device, providing the appropriate voltage and dial tone.
- **Foreign Exchange Office (FXO) interface** – connects to a PBX (Private Branch Exchange) or PSTN (Public Switched Telephone network).
- **E&M interface** – can also be used to connect to a PBX, or is used for PBX-to-PBX connections.

Additionally, Cisco gateways can connect to provider PBX's and networks using *digital* interfaces, including:

- **ISDN BRI and PRI**
- **T1/E1 CCS (Common Channel Signaling)** – employs a dedicated channel for signaling.
- **T1/E1 CAS (Channel Associated Signaling)** – a portion of each channel is utilized for signaling.

\* \* \*

All original material copyright © 2007 by Aaron Balchunas ([aaron@routeralley.com](mailto:aaron@routeralley.com)), unless otherwise noted. All other material copyright © of their respective owners.

This material may be copied and used freely, but may not be altered or sold without the expressed written consent of the owner of the above copyright. Updated material may be found at <http://www.routeralley.com>.

## VoIP Signaling Protocols

VoIP protocols are responsible for the three key *stages* of a voice call:

- Call setup
- Call maintenance
- Call teardown

The most common VoIP protocols are as follows:

- H.323 – an ITU standard
- Session Initiation Protocol (SIP) – an IETF standard
- Media Gateway Control Protocol (MGCP) – an IETF standard
- Skinny Client Control Protocol (SCCP) – Cisco proprietary

\* \* \*

All original material copyright © 2007 by Aaron Balchunas ([aaron@routeralley.com](mailto:aaron@routeralley.com)),  
unless otherwise noted. All other material copyright © of their respective owners.

This material may be copied and used freely, but may not be altered or sold without the expressed written consent of the owner of the above copyright. Updated material may be found at <http://www.routeralley.com>.

### Cisco VoIP CallManager Configuration – Voice Trunk Ports

Traditionally, Cisco IP phones contain a switch with two interfaces. The first interface connects the IP phone to the wall jack. The second interface connects the user's workstation to the IP phone. This allows a single cable to handle the user's voice and data needs.

To keep the voice/data traffic segregated, the IP phone forms a **trunk link** with the remote switch. Data traffic is tagged as a different VLAN than the voice traffic. Configuration on the remote switch (or the call-manager functioning as the switch) is simple:

```
VoIP-Switch(config)# interface FastEthernet0/1/4
VoIP-Switch(config-if)# switchport access vlan 50
VoIP-Switch(config-if)# switchport trunk native vlan 50
VoIP-Switch(config-if)# switchport mode trunk
VoIP-Switch(config-if)# switchport voice vlan 60
```

In the above example, data traffic will be tagged as *VLAN 50*, while voice traffic will be tagged as *VLAN 60*.

\* \* \*

All original material copyright © 2007 by Aaron Balchunas ([aaron@routeralley.com](mailto:aaron@routeralley.com)), unless otherwise noted. All other material copyright © of their respective owners.

This material may be copied and used freely, but may not be altered or sold without the expressed written consent of the owner of the above copyright. Updated material may be found at <http://www.routeralley.com>.

## Cisco VoIP CallManager Configuration – Dial Peers

**Dial Peers** provide call-routing, and serve two key functions:

- **VoIP dial-peers** - used to connect Cisco call-managers, gateways, or gatekeepers to other such VoIP devices. For example, two call-managers at separate branches would point to each other using VoIP dial-peer commands.
- **POTS dial-peers** – used to connect Cisco VoIP devices to an analog device or network. A dial-string is mapped to a *local* analog port on the VoIP gateway or call-manager.

Thus, the function of a Dial Peer is to match an *incoming* call with a *destination pattern*, which points to either a remote device or local interface.

To configure a VoIP dial-peer:

```
CallManager(config)# dial-peer voice 1 voip
CallManager(config-dial-peer)# session protocol sipv2
CallManager(config-dial-peer)# session target ipv4:10.1.5.50
CallManager(config-dial-peer)# destination-pattern 15865551212
CallManager(config-dial-peer)# codec g711ulaw
```

The above configuration maps a *sip* connection to a remote VoIP peer at address *10.1.5.50* for phone number *15865551212*. The *g711* codec is being employed.

To configure a POTS dial-peer:

```
CallManager(config)# dial-peer voice 2 pots
CallManager(config-dial-peer)# destination-pattern 1212
CallManager(config-dial-peer)# port 0/2/0
```

The above configuration maps an extension or phone number of *1212* to the analog voice port *0/2/0*.

(Reference: [http://www.cisco.com/univercd/cc/td/doc/product/software/ios123/123cgr/vvfax\\_c/int\\_c/dpeer\\_c/dp\\_ovrvw.htm](http://www.cisco.com/univercd/cc/td/doc/product/software/ios123/123cgr/vvfax_c/int_c/dpeer_c/dp_ovrvw.htm))

\* \* \*

All original material copyright © 2007 by Aaron Balchunas ([aaron@routeralley.com](mailto:aaron@routeralley.com)), unless otherwise noted. All other material copyright © of their respective owners.

This material may be copied and used freely, but may not be altered or sold without the expressed written consent of the owner of the above copyright. Updated material may be found at <http://www.routeralley.com>.

## Cisco VoIP CallManager Configuration – Telephony Service

Telephony-Service configuration provides a wide variety of global configuration options for a Cisco CallManger:

```
CallManager(config)# telephony-service
CallManager(config-telephony-service)#
```

The configuration files for *specific* models of IP phones are stored in flash, with a *.bin* extension. To load these configuration files:

```
CallManager(config-telephony-service)# load 7914 S00105000200
CallManager(config-telephony-service)# load 7920 7920.4.0-02-00
CallManager(config-telephony-service)# load 7960-7940 P00308000400
```

To specify the maximum number of phones that can register with the Call-Manager (dependent on the hardware/software platform):

```
CallManager(config-telephony-service)# max-ephones 12
```

To specify the maximum number of directory numbers (DNs) the Call-Manager will support (also dependent on the hardware/software platform):

```
CallManager(config-telephony-service)# max-dn 48
```

To specify the IP address of the Call-Manager on the voice VLAN:

```
CallManager(config-telephony-service)# ip source-address 10.5.5.1 port 2000
```

To specify the extension for voicemail:

```
CallManager(config-telephony-service)# voicemail 2000
```

To specify the audio file for music-on-hold:

```
CallManager(config-telephony-service)# moh music-on-hold.au
```

To configure a username and password for the Call Manager's web interface, and to enable configuration of DN's through that interface:

```
CallManager(config-telephony-service)# web admin system name AARON password CISCO
CallManager(config-telephony-service)# dn-webedit
```

To access the web-interface, use the following URL:

```
http://IPADDRESS/telephony_service.html
```

\* \* \*

All original material copyright © 2007 by Aaron Balchunas ([aaron@routeralley.com](mailto:aaron@routeralley.com)), unless otherwise noted. All other material copyright © of their respective owners.

This material may be copied and used freely, but may not be altered or sold without the expressed written consent of the owner of the above copyright. Updated material may be found at <http://www.routeralley.com>.

**Cisco VoIP CallManager Configuration – Telephony Service (continued)**

To allow the transferring of calls to an outside line, using a specific dial-pattern (such as dialing 9 first, and then a seven-digit number):

```
CallManager(config-telephony-service)# transfer-pattern 9.....
```

To configure the auto-attendant for night-service:

```
CallManager(config-telephony-service)# night-service code *11
CallManager(config-telephony-service)# night-service day Mon 18:00 06:00
CallManager(config-telephony-service)# night-service day Tue 18:00 06:00
CallManager(config-telephony-service)# night-service day Wed 18:00 06:00
CallManager(config-telephony-service)# night-service day Thu 18:00 06:00
CallManager(config-telephony-service)# night-service day Fri 18:00 06:00
```

To configure a directory of extensions:

```
CallManager(config-telephony-service)# directory entry 1 3000 name Aaron
CallManager(config-telephony-service)# directory entry 1 3001 name Petey
CallManager(config-telephony-service)# directory entry 1 3002 name Team Awesome
CallManager(config-telephony-service)# directory entry 1 3003 name Team Tiger
CallManager(config-telephony-service)# directory entry 1 3003 name Jack Nicholson
CallManager(config-telephony-service)# directory entry 1 3004 name Nick Cage
```

To define the URL's for ephones:

```
CallManager(config-telephony-service)# url directories http://10.5.5.1/localdirectory
CallManager(config-telephony-service)# url services http://10.5.5.1/menu.php
CallManager(config-telephony-service)# url authentication http://10.5.5.1/auth.php
```

Some configuration changes require a reset of the phone(s). To reset all phones connected to the Call Manager:

```
CallManager(config-telephony-service)# reset all
```

(Reference: [http://www.cisco.com/en/US/tech/tk1077/technologies\\_configuration\\_example09186a00800ffdcc.shtml](http://www.cisco.com/en/US/tech/tk1077/technologies_configuration_example09186a00800ffdcc.shtml))

\* \* \*

All original material copyright © 2007 by Aaron Balchunas ([aaron@routeralley.com](mailto:aaron@routeralley.com)), unless otherwise noted. All other material copyright © of their respective owners.

This material may be copied and used freely, but may not be altered or sold without the expressed written consent of the owner of the above copyright. Updated material may be found at <http://www.routeralley.com>.

## Cisco VoIP CallManager Configuration – DN's and Extensions

**Directory Numbers (DNs)** are assigned to phones for identification and to allow call-routing. Call Managers usually support a finite number of DN's, depending on the hardware/software/licensing platform.

**Extensions** are then *mapped* to these DN's. The Call Manager identifies the phone using a DN, but users *call* a phone using the extension number. To configure a DN:

```
CallManager(config)# ephone-dn 5 dual-line
CallManager(config-ephone-dn)# number 3001
CallManager(config-ephone-dn)# description Call at your own risk
CallManager(config-ephone-dn)# name Petey
```

In the above example, *dn 5* is configured as a *dual-line*, which allows for call transfer, conferencing, and call waiting. DN's/extensions that serve solely as a voicemail box can leave off the *dual-line* parameter.

An extension number of *3001* has been assigned to this DN.

(Reference: <http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122newft/122limit/122z/122zj15/cme30cr/icr30am.htm#wp1008071>)

## Cisco VoIP CallManager Configuration – Phones

To configure the actual VoIP phone:

```
CallManager(config)# ephone 7
CallManager(config-ephone)# mac-address 0011.2233.4455
CallManager(config-ephone)# type 7920
CallManager(config-ephone)# button 1:5
CallManager(config-ephone)# pin 12345
CallManager(config-ephone)# speed-dial 1 3002 label "Team Awesome"
```

In the above example, *ephone 7* has been identified as having a *mac-address* of *0011.2233.4455*, and a model number of *7920*.

The *button* command maps the first button (or extension on the phone – Cisco phones support multiple extensions) with *DN* number *5* (per our previous configuration, this maps to extension *3001*).

Finally, the phone's pin number for voice mail has been set to *12345*, and a *speed-dial* entry has been added for extension *3002*.

(Reference: <http://www.cisco.com/univercd/cc/td/doc/product/software/ios122/122newft/122limit/122z/122zj15/cme30cr/icr30am.htm#wp1014674>)

\* \* \*

All original material copyright © 2007 by Aaron Balchunas ([aaron@routeralley.com](mailto:aaron@routeralley.com)), unless otherwise noted. All other material copyright © of their respective owners.

This material may be copied and used freely, but may not be altered or sold without the expressed written consent of the owner of the above copyright. Updated material may be found at <http://www.routeralley.com>.